



EXTREME MARQUEES

CAR AWNING RANGE

DESERT SHADE 270°

INSTRUCTION MANUAL

SET-UP INSTRUCTIONS



STEP 1.

Before begin the set-up, ensure the area around the car awning is clear from trees and any other hazards.



STEP 2.

Unzip the car awning protective cover bag.



STEP 3.

Undo the two Velcro straps around the car awning and roll down the fabric.



STEP 4.

Attach the guide rope through the black loop of the first arm of the frame.



STEP 5.

Using the now attached guide rope, start to open the awning.



STEP 6.

Walk the awning around the back of the car until complete expanded to 270°.



STEP 7.

Loop the guide rope around the car roof rack. Tighten the rope until the car awning fabric has no creases.



STEP 8. (Optional)

For extra support the 3 built-in telescopic legs can be lowered from the frame arms. These can also be strapped and pinned to the ground.



STEP 9. (Optional)

There are four extra tie-down straps and pins to strap the car awning to the ground and help direct rain water off the awning.



EXTREME MARQUEES

CAR AWNING RANGE

DESERT SHADE 270°

INSTRUCTION MANUAL

PACK-DOWN INSTRUCTIONS



STEP 1.

Take off any tie-down ropes and pins from the awning. Then undo the guide rope from the back of the car roof rack.



STEP 2.

Using the guide rope, walk the awning around until all the frame arms are folded into the protective cover.



STEP 3.

Unstrap the guide rope and tightly roll up the car awning fabric into the protective cover.



STEP 4.

Once the fabric is rolled up, secure with the two Velcro straps.



STEP 5.

Zip the protective cover bag closed.

NEVER TRAVEL WITH AWNING OR AWNING BAG OPEN.